

Installation Instructions

NYLI-6P

6" Stem Mounted Line Voltage Cylinder

READ PRIOR TO ATTEMPTING INSTALLATION
ALWAYS TURN OFF MAIN POWER BEFORE INSTALLATION
INSTALLATION SHOULD BE CARRIED OUT BY YOUR LOCAL ELECTRICIAN

⚠ FIRE/ELECTRICAL HAZARD: INSTALL ACCORDING TO NATIONAL ELECTRIC CODE AND ANY APPLICABLE MUNICIPAL CODE REQUIREMENTS. - This equipment is intended to be installed only by qualified personnel. The installation must be made in accordance with the current edition to the National Electric Code and all applicable state and local building codes. The final installation must be approved by the appropriate qualified electrical/building inspector(s). Improper installation may result in a fire or electrical hazard. Be sure the electrical power to the circuit has been disconnected before installing this electrical system.

⚠ RISQUE D'INCENDIE / D'ÉLECTRICITÉ: INSTALLER SELON LE CODE ÉLECTRIQUE NATIONAL ET TOUTES LES EXIGENCES RELATIVES AU CODE MUNICIPAL APPLICABLE. - Cet équipement est destiné à être installé uniquement par du personnel qualifié. L'installation doit être faite conformément à l'édition actuelle du Code national de l'électricité et de tous les codes de construction locaux et nationaux applicables. L'installation finale doit être approuvée par un ou plusieurs inspecteurs qualifiés en électricité / bâtiment. Une installation incorrecte peut entraîner un incendie ou un risque électrique. Assurez-vous que l'alimentation électrique du circuit a été déconnectée avant d'installer ce système électrique.

STEM MOUNT INSTALLATION

⚠ INSTALLATION SHOULD BEGIN FROM CYLINDER CAP TO TOP.

1. Ensure electrical power is off.
2. Insert power cord through nut, cylinder cap, coupler, stem(s), reducer and swivel.
Connect stem(s) to cylinder and insert reducer between swivel and stem. (Figure 1)
3. Insert power cord and swivel through canopy and cut excess cord length. (Figure 2)
4. Attach junction box plate (included) to junction box and connect to supply wires in junction box. (Figure 3)
5. Screw swivel into junction box plate. Tighten set screw to secure canopy. (Figure 4)
6. Attach cylinder to cylinder cap through keyhole slots. (Figure 5)
7. Twist the cylinder cap to lock and tighten screws inside cylinder. (Figure 6)
8. Connect ideal connector from power cord to medium base socket. (Figure 7)
9. Attach medium base socket to reflector and screw in lamp (not included). (Figure 8)
10. Squeeze torsion springs on reflector and insert into bracket inside the cylinder. (Figure 9)
11. Push reflector into cylinder until flush.

