

Installation manual for:

**7815G33C
7815G33G
7815G33GT
7815G33SS**

Dimensions: D33"H52"L15

Collection: Verona

Bulb Type : E12 bulb not included

Lamp Frame Weight (lbs):28.5

Total Weight (lbs): 42.3




Thank you for choosing our product(s).

Our Company is actively involved in every step of the production. Our product(s) are designed to be utilized for every application that graces your home or business.

We pride ourselves in providing the most prompt and courtesy service to all of the valued customers.

Please find the enclosed detailed instruction and read carefully for proper installation. If you have any questions, our professional customer service team is committed to assisting you, please call our toll free HOTLINE AT:

1-888-388-3390



SAFETY

Warning: MAKE SURE THE ELECTRICITY TO THE WIRES YOU ARE WORKING ON IS SHUT OFF, BY EITHER REMOVING THE FUSE OR TURNING OFF THE CIRCUIT BREAKER.

CAUTION


- Before assembling the lighting fixture, please read all instructions carefully.
- All frame & crystal components are fragile, please handle with care.
- Required supply circuit : 110 - 130V/60Hz
- Labeled wires are "L" for live wire, "N" for neutral wire, "E" for ground wire.
- Never install fixture on damp ceiling, the room should be dry and well ventilated
- All electrical components must be installed by licensed electrician and in accordance with the National Electrical Code and the appropriate local electrical codes.

Unpack the Package

Please open the box carefully and check all the items are inside the box. If you have any installation, assembling and missing parts questions, please call our Customer Service department at 1-888-388-3390. Please have model number (at the front page), where you purchase from and any other relevant information ready, our customer service team will provide comprehensive and worry free service to our valued customers.

Step 1























Frame Assembly Diagram



7815G33 D33"H52"L15



















Please use the partslist to ensure you are not missing any parts.

7815G33 PARTS LIST

Part#	Picture	Description	Qty	Check list
ZA		Canopycover(Ø5.3"H1.2") (Canopy part)	1	
ZB		Crossbar 4"(Canopy part)	1	
ZC		Canopy ring (Canopy part)	1	
ZD		Canopy lock (Canopy part)	1	
ZE		ChainØ0.197"L59"(Canopy part)	1	
P01		Fixture loop	1	
P02		Ground Screw(M4)	3	
P03		Glass plate(Ø4.7")	1	
P04		big pipe cover	8	
P05		Vase	4	
P06		big pipe cover	6	
P07		Vase	2	
P08		Straight Pipe	1	
P09		plated Cylinder Screw Connector	2	
P10		All thread	2	
P11		Candle cover(Ø0.87"L4.13")	15	
P12		Glass plate(Ø4.7")	15	
P13		Crystal Drop Holder	15	
P14		Socket	15	
P15		All thread	30	
P16		Glass S-shape Arm	5	
P17		Glass ring	15	













03

7815G33 D33"H52"L15

Part#	Picture	Description	Qty	Check list
P18		Round Metal Slice (Ø5.1")	1	
P19		Set Screw	17	
P20		Hickey	1	
P21		Base(Ø5.19")	1	
P22		Glass plate(Ø5.9")	1	
P23		Straight Pipe	1	
P24		Glass S-shape Arm	10	
P25		Round Metal Slice (Ø7.08")	1	
P26		Hickey	1	
P27		Base(Ø7.16")	1	
P28		Glass plate(Ø7.9")	1	
P29		Straight Pipe	1	
P30		Vase	1	
P31		Glass plate(Ø4.7")	1	
P32		Small flying saucer	1	
P33		Bottom lock	1	
P34		6.5mm Crystals	10	
P35		Main electrical wire(Golden/ Transparent color L173.1")	1	

04


7815G33 D33"H52"L15

Part#	Picture	Description	Qty	Check list
A		1050-14#*5+911-3"	5	
B		1050-14#*32 +2024-14#*1 +1050-14#*16*2	5	
C		1050-14#*1+911-2"	75	
D		1050-14#*2+911-3"	5	
E		1050-14#*5*2 +2024-14#*1 +1050-14#*1 +911-3"	10	
F		2024-14#*1+1050-14#*3+911-3"	10	
G		2024-14#*1+1050-14#*1+911-3"	10	
H		1050-14#*9	10	
I		1050-14#*10+911-3"	10	
J		1050-14#*10+911-3"	5	
K		1050-14#*6+911-3"	5	
L		1050-14#*9+701-40#	1	

7815G33 D33"H52"L15

Step 2

Canopy Installation Instruction



"L" = Hot wite
 "N" = Neutral wite
 "E" = Ground wite

7815G33 D33"H52"L15

IMPORTANT: Test sockets with bulb before dressing the fixture.


1. Attach the crossbar to the electrical box.
2. Pass the lamp wire and ground wire through the loop, canopy ring and center hole of canopy cover.
3. Screw 2.5" nipple into the crossbar and fasten with hex-nut.
4. Pull wires up through the nipple.
5. Screw loop only onto threaded pipe.
6. Hang the fixture on chain.
7. Make the electrical connections as detailed in the drawing above.
8. Secure the canopy cover with threaded canopy ring

07

7815G33 D33"H52"L15

Step 3

Frame Assembly Diagram



Frame Assembly Instructions

Installation:

Please read all instructions carefully. Before you proceed to install, make sure that the power supply is turned off and remains off until installation is complete. Please note that each part has been assigned a number. Please proceed in a numerical order.



1. Hang the chain (01) on the ceiling.
2. Hang the lamp body (02) on the chain (01).
3. Break up the lamp body (02) and assemble the glass arm (03) to the lamp body (02) then assemble the lamp body (02).
4. Hang the lamp body (04) on the chain (02).
5. Break up the lamp body (04) and assemble the glass arm (05) to the lamp body (04) then assemble the lamp body (04).
6. Put the glass ring (06) and glass dish (07) on the glass arm .
7. Hang (08)/(09)/(10)/(11)/(12) on the lamp body (04) .
8. Hang up the crystal in accordance with the Crystal Dressing Diagram.

The end !

Step 4

Crystal Dressing Diagram

When dressing the chandelier with the crystals please remember to wear either rubber or cotton gloves. So as to prevent any damage or smudging on the crystals.



7815G33 D33"H52"L15

Congratulations !

You are now done installing your Elegant Lighting fixture. Sit back and admire each crystal as it will become the statement piece for your room/house.

If you require any additional assistance, please contact us at 1-888-388-3390.

Thank you.

7815G33 D33"H52"L15

Cleaning and Maintenance of Chandelier Frame

The finish on our chandelier frames and fixture frames is protected by a durable coating of lacquer. To clean, use a clean soft, dry cloth. Do not use any metal polishes, cleaners, abrasives or any substance which could remove the protective finish.

Failure to follow these instructions automatically voids the guarantee.

Cleaning and Maintenance of Crystals

Wet a chamois in clean warm water and wipe gently, then polish with a dry chamois.

To Order Crystal Replacement Parts

Should you require replacement crystals or pins (the metal connectors attaching the crystals), contact the store where the product was purchased or contact us at the address shown on the reverse side. For ease of ordering, you may use the original crystal trimming instructions provided with this product and circle the items you wish to order, indicating the quantity by writing the number needed adjacent to the circle and faxing it to our customer service department at 215-423-8882. You will be contacted with prices prior to shipment. All orders must be pre-paid.

7815G33 D33"H52"L15

Elegant Lighting Warranty

The finish and frame of your new chandelier or fixture warranted for a period of two (2) years from the date of purchase. Our company will, at its option, repair or replace any frame that has a defect in the materials or workmanship during the warranty period. All crystals are guaranteed for their original quality during the life of the chandelier. Breakage is not covered by this warranty. To make a claim under this warranty, contact our customer service department at the address and phone number shown below. A written return authorization form will be sent to you with specific instructions.

**CUSTOMER SERVICE DEPARTMENT
500-550 E. Erie Avenue
Philadelphia, PA 19134
Tel : 215-423-8880
Fax : 215-423-8882**

7815G33 D33"H52"L15

Returns and Conditions of Warranty

Returns must be pre-authorized by contacting our customer service department at the address on the reverse side. Returns will only be accepted with a written return merchandise authorization and return shipping charges pre-paid. We reserved the right to inspect all returned merchandise to fully determine the nature of any defect. This guarantee shall not apply to any product that has been changed, altered or otherwise modified, nor shall it apply to any product that has been repaired or altered by anyone other than a pre-authorized facility. We will not be responsible for any breakage or damages incurred during transit, nor for crystal parts or metal frame part that have been subject to misuse, negligence, accident or inappropriate handling. Also, we will not be held responsible for damage incurred during improper installation or wiring by others, nor for damages resulting from a failure to follow the recommended maintenance or installation procedures. This guarantee is issued in lieu of any and all other guaranteed or warranty, whether written or implied and any and all other obligations or liabilities. Further, we neither authorize nor permit any other person or firm to assume for us, any liability in connection with the sale of our products.